




autodigitizing

Getting Started

Adjustments: Appliqué

1. Open autodigitizing, or click New Design  to get a blank screen if autodigitizing is already open.
2. Set Display Preferences, selecting hoop size for a 120 mm tall design.
3. Click the Insert Image  icon. Insert C:/autodigitizing/artwork/Modern Heart
4. Leave all Shape Depiction settings at defaults and click OK.
5. Set height to 110 in the Resize box.
6. DO NOT GENERATE.
7. Right click inside the heart to select the outline.
8. Select the Property  icon or press the Spacebar to open the Area Properties Sheet.
9. Place a dot in front of Appliqué. In the Cover settings box, set Width to 3.0. Leave all other settings at their default.
10. Click the Generate button on the bottom of the Area Properties sheet.
11. The heart will automatically be generated as an appliqué, and will stitch a running placement stitch, stop for the appliqué fabric, stitch a tack down stitch of your choice, stop for trimming excess fabric, then stitch the column appliqué stitch.
12. Save the design as Heart Appliqué.
13. Export the design in the correct format for your machine as HeartApplique.

