











## DESIGNER DIAMOND™ Technique Step by Step #12 - 8 Way Stitch Borders


1. In Sewing Mode, touch 
2. Touch Stitch Menu 
3. Select L Menu 
4. Select L2:30 
5. Touch Stitch Menu 
6. Select T Menu 
7. Select Straight Stitch sewn to the right  four times.

This is how the stitch appears on the screen:



8. Touch Stitch Menu 


9. Select L Menu 

10. Select L2:30 

11. Touch Stitch Menu 

12. Select T Menu 

13. Select Straight Stitch sewn to the right ► four times.



This is how the stitch appears on the screen:



14. Touch Stitch Menu 


15. Select L Menu 

16. Select L2:30 

17. Touch Stitch Menu 

18. Select T Menu 

19. Select Straight Stitch sewn to the right ► four times.



This is how the stitch appears on the screen:

20. Touch Stitch Menu



21. Select L Menu



22. Select L2:30




23. Touch Stitch Menu



24. Select T Menu




25. Select Straight Stitch sewn to the left ◀ four times.




This is how the stitch appears on the screen:

26. Touch Stitch Menu 


27. Select L Menu 

28. Select L2:30 

29. Touch Stitch Menu 

30. Select T Menu 

31. Select Straight Stitch sewn to the left ◀ four times.



This is how the stitch appears on the screen:

32. Touch Stitch Menu 

33. Select L Menu 

34. Select L2:30 


35. Touch Stitch Menu



36. Select T Menu



37. Select Straight Stitch sewn to the left ◀ four times.



This is how the stitch appears on the screen:

You can begin sewing directly from Program Mode or Touch Stitches”.



to save the combination in “My

When you sew out the border, it will connect continuously.

Stitch with stabilizer underneath the fabric.