



## Button Foot with Placement Tool #412934545

This presser foot for sewing on buttons raises the button slightly off the fabric to give a slight thread shank to enable easy buttoning, and prevent the button from being sewn too tightly to the fabric.



1. Slide the Retractable Thread Shank Guide into the desired position. All the way back will give you no thread shank. The first position will give you a shorter shank for light weight fabrics. The second position (all the way forward) will give you a longer thread shank for heavier fabrics.




2. Snap your Button foot onto your machine. To make it easier, have your presser foot in the "extra" high position. Tip the front of the foot up slightly, and slide the foot into place.

Button Placement Tool



3. Insert the Button Placement Tool into the holes of the button.

4. Insert the Button Placement Tool with the button in place into the slot in the foot. The button will automatically be placed in the correct position for sewing.



5. Remove the Button Placement Tool.
6. Select "Button Sewing" on your Sewing Advisor. Adjust the Stitch Width if necessary according to the width between the holes in the button.
7. Sew on your button following the instructions in your Users Guide.