

Husqvarna Viking DESIGNER DIAMOND™ Gems of Wisdom



Saving Designs and Stitches to USB Stick

When updating, you may want to save the designs and stitches on your Designer Diamond to your USB Embroidery Stick.

Saving Stitches:

1. Plug in your Husqvarna Viking USB Embroidery Stick.

2. Touch .

3. Touch Stitches Menu .

4. Select My Stitches menu.

5. Touch a stitch to load it.

6. Touch Save to My Files .

7. The machine will give you a default name. If you want to change the name, touch .

8. Choose the External Device Icon .

9. Select the USB stick .

10. Choose Open Folder .







11. Touch to save the stitch.

12. Touch Delete to remove the first program.









13. Repeat for every stitch.

14. When finished, touch to close program mode.







To Open the Saved Stitches:

1. Choose Start Menu  .
2. Touch File Manager  .
3. Choose the External Device Icon  .
4. Select the USB stick  .
5. Choose Open Folder  .
6. Locate the stitch and touch to highlight it.
7. Touch  .

Saving Designs:

1. Plug in your Husqvarna Viking USB Embroidery Stick.
2. Toggle to Embroidery Mode  .
3. Touch Start Menu  .
4. Locate and select design to load it.
5. Touch Save to My Designs  .
6. The machine will give you a default name. If you want to change the name, touch  .
7. Choose the External Device Icon  .
8. Select the USB stick  .
9. Choose Open  .
10. Touch  to save the design.
11. Repeat for every design.

To Open the Saved Stitches:

1. Choose Start Menu  .
2. Touch File Manager  .
3. Choose the External Device Icon  .
4. Select the USB stick  .
5. Choose Open Folder  .
6. Locate the design and touch to highlight it.
7. Touch  .