

Tips for 1/4" Seam Allowance and The New Edge Stitching Foot #412 79 67-45 for piecing quilts

E:1 the 1/4" stitch is exactly 1/4" from the edge of the new 7mm A Presser foot. It is easy to select the stitch on all computer Husqvarna Viking machines with one touch 1/4" stitch, and start piecing!


The Edge Stitching Foot was originally designed for sewers to topstitch perfectly along an edge, adjusting needle position as desired. Quilters quickly found it perfect for piecing as the flange guided the fabric perfectly for the most accurate piecing possible.

Husqvarna Viking Designer SE

E:1, the 1/4" stitch, is exactly 1/4" from the edge of the A presser foot.

Many quilters like a flange to guide the edge of the fabric. Simply snap on the Edge Stitching Foot, and adjust the needle position to 2.5 for a scant 1/4". Quilters have a very definite preference, as to how "scant" they would like their 1/4". With 29 needle positions, you can set it perfectly for your preferences by adjusting the needle position.




Is this something you would use often? Save it in "My Stitches". Just touch . Touch an empty position. Your stitch, with the scant 1/4" exact settings will be saved there. Next time you want to piece, just go to your "U", My Stitches Menu, and your stitch will be waiting there for you, ready to go!

When you use your new 7mm Edge Stitching Foot with A2, straight stitch, you will have a perfect 3/8" seam allowance! Isn't that easy! It makes perfect tucks, when you fold the fabric, and guide the fold against the ledge on the foot.



Husqvarna Viking Designer I

E:1, the 1/4" stitch, is exactly 1/4" from the edge of the **new 7mm** A presser foot. It is easy to select the stitch, and start piecing!

Many quilters like a flange to guide the edge of the fabric against. Simply snap on the **new 7mm** Edge Stitching Foot, and select A3, right needle position for a scant 1/4" stitch. Sometimes quilters like to

"tweak" the scantness of the 1/4" stitch. To change needle position touch . Adjust your width, + or -, to achieve just the seam you want. There are 25 needle positions on the all Husqvarna Viking computer machines.

Is this something you would use often? On Designer I and Quilt Designer II, save it in "My Stitches". Just

touch  and . Touch an empty position. Your stitch, with your exact settings will be saved there. Next time you want to piece, just go to your "U" My Stitches Menu or your favorite stitch on your Quilt Designer II, and your stitch will be waiting there for you, ready to go!

When you use your new 7mm Edge Stitching Foot with A2, straight stitch, you will have a perfect 3/8" seam allowance! Isn't that easy! It makes perfect tucks, when you place the fabric edge against the guide on the foot.