

Designer I Design Download Instructions

Designer I:

1. Start the download of the design in Designer I (.shv) format.
2. Save the zipped file in a folder of your choice or to a 3.5" diskette.
3. Find the file and double click on it to unzip the file. The file is an .exe-file and is selfextracting.
4. Click OK in the first dialogue box.
5. Click on "unzip" and save the files on to an empty 3.5" diskette and the design is ready to use in your Husqvarna Viking Designer I. The design will always be in Menu 1, position 1, so be sure to use an empty diskette.