

CD Case

By Marie Duncan

Stitch up this handy case to store your cds in. You can use it at home, at the office or in your car!

The featured design, **200258002**, is from HUSQVARNA VIKING® Collection 258, Texture Hoop Visions. It is the free design for the month of November, 2014.

To download the design, go to the HUSQVARNA VIKING® website. Click on **Be Inspired/Inspiration** and **Sewing Projects**. Choose the project for November and click on **View Project**. Then click on **Download Design** to access the design.

The entire collection, Texture Hoop Visions, is available for purchase from your local HUSQVARNA VIKING® dealer.

Sewing Supplies:

- | | |
|--|-----------|
| • Texture Hoop | 920225096 |
| • Clear ¼" Piecing Foot with Guide | 412927445 |
| • Interchangeable Dual Feed | 920219096 |
| • Changeable Quilter's Guide Foot | 413155545 |
| • INSPIRA® embroidery needle, size 90 | 620071896 |
| • INSPIRA® Aqua Magic Plus | 620114596 |
| • INSPIRA® In-R-Form batting Alternative | 620131596 |
| • 1¼ yards solid cotton | |
| • ¼ yard cotton print 1 | |
| • ½ yard cotton print 2 | |
| • ½ yard of 1" wide white ribbon | |
| • ½ yard of ½" wide white sheer ribbon | |
| • Robison-Anton 40 wt. rayon embroidery thread | |
| • Bobbin thread | |
| • Cotton sewing thread | |
| • Rotary cutter, cutting mat and ruler | |

Cut:

From solid cotton:

- One piece 12" long x 14" wide for embroidery
- One piece 38¼" long x 6½" wide for case front
- One piece 44" long x 6½" wide case back/lining



From cotton print 1:

- Three pieces 6½” wide x 9” long




From cotton print 2:

- Four pieces 6½” wide x 9” long
- Three strips 2¾” long x width of fabric for binding

From the INSPIRA® In-R-Form batting Alternative

- One piece 44” x 6½”

Embroider:

1. Insert a size 90 INSPIRA® embroidery needle.
2. Thread with Robison-Anton 40 wt. rayon embroidery thread on top and bobbin thread in the bobbin.
3. Load design **200258002**. 
4. Hoop the 12” x 14” piece of solid cotton with Aqua Magic Plus stabilizer in the Texture Hoop. Attach the hoop to the embroidery unit.
5. Touch **GO**  to move to Embroidery Stitch Out Mode.
6. Cut the 1” wide ribbon in half. Clip the two pieces in place on your Texture Hoop centered top to bottom and side to side.
7. Cut the ½” wide ribbon in half, place on the diagonal marks and clip in place.
8. Embroider the design.
9. When the design is complete, touch and hold **Baste** . Choose **Baste around the Hoop area**.
10. Touch **Start/Stop** and baste the ends of the ribbon in place.
11. Trim ¼” outside the basting.
12. Remove the stabilizer.

Sew:

1. Thread with cotton sewing thread top and bobbin.
2. Fold all of the 6½” x 9” cotton pieces right sides together to form a piece 6½” x 4½”. These will be the pockets.

3. Snap on your Clear ¼" Piecing Foot with Guide.



4. Select stitch **A1:02**.

5. Sew the 6½" edges together.

6. Turn and press. You now have two finished long edges and two short raw edges.

7. Place the embroidered 6½" square right sides together with the 38¼" x 6½" case front piece matching the 6½" edges.

8. Sew.

9. Press the seam allowance to one side.

10. Place the embroidered case front on top of the 44" x 6½" INSPIRA® In-R-Form.

11. Attach your Interchangeable Dual Feed.

12. Snap on your Changeable Zig Zag Foot.



13. Select stitch **A1:11**.

14. Zigzag along all four edges securing the layers together.

15. Pin the pockets in place beginning with the top one. It should be 2" down from the seam between the embroidered square and the top piece.

16. Place the remainder of the pockets 1" apart as shown.

17. Stitch along the pocket edges, securing them in place.



18. Select stitch **E3:55**.


19. Snap on your Changeable Quilter's Guide Foot.

20. Align the flange of the foot with the bottom of the pocket, and stitch along the bottom edge of each of the pockets.

21. Snap on your Changeable Zig Zag Foot.

22. Layer the case front and case back/lining. Stitch around the edge, securing the layers together.

| |
|--------------------|
| Embroidered Square |
| 2" |
| Pocket |
| 1" |
| Pocket |
| 1" |
| Pocket |
| 1" |
| Pocket |
| 1" |
| Pocket |
| 1" |
| Pocket |
| 1" |
| Pocket |
| 1" |
| Pocket |
| 1" |
| Pocket |
| 1" |
| Pocket |

23. Select stitch **A1:02** .

24. Stitch the binding pieces end to end to create one long strip.

25. Fold in half lengthwise and press.

26. Bind the outside of the case, mitering the corners.

27. Cut a 4" piece from the leftover binding for the hanger. Fold in each end 1/4" to the wrong side.

28. Fold each raw edge in to meet the center fold. You now have a finished strip. Stitch to secure the open edge.

29. Place on the top of the case and stitch in place.

Fill with your favorite cds and dvds, and sit back and admire your good work!

