

APRON



Finished size: 23''x 33'', (58cmx 85 cm)

Sewing Supplies

- 1 yard of 55'' (100cm x 140cm) wide cotton canvas fabric
- Sewing thread to match the fabric
- 40 wt embroidery thread (if you add an embroidery)
- Bobbin thread (for the embroidery)
- Scissors
- Bias binding 1'' wide (2.5cm) 5 yards (incl. pocket)

HUSQVARNA VIKING® Accessories

- HUSQVARNA VIKING® Sewing (and/or Embroidery Machine)
- INSPIRA® Universal Needle Size 80 6200703-96


3/8" (1 cm) seam allowance included in all measurements

CUT

Fabric according to drawing.

Cut bias bindings in three pieces.

1. For the top edge, 12'' (30cm.)
2. For the sides and bottom of apron, approximately 67'' (170cm). Test to bring it from X to Y.
3. The last piece of bias binding, 2 yard (2 meters), will be used for the piece around the neck and to tie the apron.



1. Iron the bias binding, see picture. You should make one side of the bias binding a bit wider than the other. This is to make it easier to be sure the zig-zag will be stitched in the edge on the backside.



2. Sew the bias binding, by using a narrow zig zag stitch 1.5 on both width and length. Start with the shortest piece on the top edge of the apron(Z). Next is the long bias binding around the edge (from X to yY.)
3. Finally cut a long piece of bias binding, 80'' (2 meters) long to use for bringing the apron around the neck, stitch along the armhole cut outs, and the rest of the bias binding is to use to tie the apron on the back. *Make sure you can put the apron over your head before you sew.* The neckline bias binding measures approximately 22'' (56cm).
4. Sew the 22'' (56 cm) with a zig zag length before you add it on to the apron. (Put a pin on the center of the long bias binding and measure 11'' (28 cm) from the middle out, on both sides of the center.)
5. If desired, make a small pocket for the apron.
6. Add bias binding on the top edge of the pocket.
7. Use a zig zag stitch on the three other edges, or use an overlock to overcast the raw edges of the pocket.
8. Iron the seam allowance to the backside of the pocket fabric, and topstitch it in place using a straight stitch.

Hint Personalise the apron by adding a text on the apron or sew an appliqué.