

Magician Outfit

The Magician outfit is sewn in three parts: jogging outfit, cape and a hat.



Sewing Supplies

- Burda pattern 3689
- Single jersey for jogging outfit according to Burda pattern
- Fabric for cape 1 3/4 yds (1.60 cm) (or length of the cape x 2)
- Red lining for cape 1 3/4 yds (1.60 cm) (or length of the cape x 2)
- 6" (15 cm) black drawstring
- 1/3 yard (30 cm) Golden fabric for stars appliqué
- Fusible web (Vliesofix or Steam a Seam 2)
- Black sewing thread
- 5/8 yd (50 cm) felt
- 5/8 yd (50 cm) Vlieseline or fusible interfacing
- Tear-A-Way™ Stabilizer
- Optional:
 - Husqvarna Viking Open Toe Foot (412 27 70-45)
 - Husqvarna Viking Edge Stitching Foot (412 40 77-45)

JOGGING OUTFIT

Cut and sew the jogging outfit according to the Burda instructions.

CAPE CUT

Fold the fabric for the cape double. Mark a neckline in the corner as illustrated. Measure the length of the child from the neck to desired length and mark needed length on the folded fabric + 3/8" (1 cm) seam allowance (A). Cut the cape in outer fabric and lining. (Illustration A).





Illustration A.



PATTERN FOR THE STARS