



Felt to Fabric – Child’s Picture Book

Create a needle punched felt appliqué on a foundation fabric. With the Husqvarna Viking® ER10™ Embellishing Machine there is no thread or bobbin needed.

For the Child’s “picture” book, you need:

- Orange colored wool foundation fabric (wool felt) for book front and back cover 11 1/2” x 6 1/4” (28 x 15 cm)
- Additional wool foundation fabric (wool felt) in same size for book pages
- Blue wool fabric/felt for the little car
- Scrap pieces of yellow, light blue and pink wool fabric/felt for the three balloons and the little girl
- Pictogram pen 412 08 38-48
- Fabric scissors
- Husqvarna Viking® ER10™ Embellishing Machine
- Husqvarna Viking® sewing machine
- Edge Stitching Foot 412 79 67-45

CUTTING

Trace the shapes on the different colored wool fabrics/felt using the Pictogram pen.

EMBELLISH/FELTING/ PUNCHING

- Place the cut yellow girl shaped wool on top side of the orange foundation fabric.
- Start in the center of the shape, step on the foot control so the needles go up and down into the fabric. This is called needle felting. Move over the entire shape with a slight amount of needle felting on all areas to “baste” it in place. Then needle felt over the shape well moving over the entire shape until the yellow wool is completely needle felted into the orange foundation fabric.
- Continue the same way with to needle felt the car and the balloons into the foundation fabric.
- The strings on the balloons are sewn with a straight stitch on a

Husqvarna Viking® Sewing Machine threaded with decorative Rayon thread.

SEW/CONSTRUCT THE BOOK

- Place the orange cover piece on a yellow piece of felt the same size. Trim to 11 1/2” x 5 3/4” (29 x 15cm) with a pinking shears.
- Snap on the Clear Edge Stitching Foot. Select right needle straight stitch. Topstitch the two layers together sewing with the guide on the foot along the edge of the book.
- Cut additional pages the same size with a pinking shears. We added a pink and blue page stitched together. Layer the pages and stitch at the middle along the 5 3/4” (29 x 15cm) to create the “spine” of the book. Add a ribbon tied around the spine of the book.
- Ask your children or grandchildren to create pictures to add to the pages of the book.