



Yarn to Fabric – Fashion Handbag

Sew a beautiful wool handbag with three dimensional details by needle felting yarn onto a wool foundation fabric.

YOU NEED:

- Black wool foundation fabric
- Multicolored wool yarn
- Fabric scissors
- Burda pattern no 8305, model F
- Lining fabric
- Husqvarna Viking® ER10™ Embellishing Machine
- Husqvarna Viking® sewing machine

CUTTING

Cut out the pieces for the bag as described in the Burda pattern.

EMBELLISH/FELTING/PUNCHING

- Place the yarn on the right side of the front pieces of the bag front. Arrange the yarn in the swirling design as pictured or create your own design.
- Start in the center of the bag and needle loosely over most of the bag piece to “baste” the yarn in place. (Don’t forget to take away any pins holding the yarn in place before you come close to them with the needles.)
- Start in the center of the bag and needle felt loosely over most of the bag piece to “baste” the yarn in place.
- Machine needle felt over the entire bag piece until all yarn is securely needle felted into the foundation fabric.

SEWING

Follow the instructions in the Burda pattern no 8305 to complete the handbag.

