

Husqvarna Viking DESIGNER DIAMOND™ Gems of Wisdom



.wav files

You can use your own sound files in your Husqvarna Viking Designer Diamond for Button/icon disabled, Warning/attention, Embroidery finished and Start-up sound.



Finding .wav Files:

- We “googled” wav file formats and found lots and lots of .wav files to download. The files need to be short. The sound length for icon acknowledgement, button/icon dabled alert or attention pop-up messages is a maximum of 5 seconds. For Start up and Embroidery Finished the maximum sound length is 30 seconds.
- Depending on the source of your files, they may be zipped. If they are zipped, unzip them using WINZIP or a similar program.
- Keeping The World Sewing is included as a .wav file on your USB Embroidery Stick.



Saving the .wav file to your Designer Diamond:

1. After downloading the .wav file, save it to your USB Embroidery Stick. Place your USB Embroidery Stick in your Designer Diamond.



2. Touch



3. Touch File Manager



4. Touch external Device



5. Touch USB Embroidery Stick



6. Touch Open folder



7. Touch Sound




8. Touch Open folder

9. Touch the .wav file you want to save to highlight it.

10. Touch Copy 



11. Touch My Files 

12. Touch Paste 


13. Touch  to close the window. Your .wav file is now saved on your Husqvarna Viking Designer Diamond.



Changing your Audio Sound Settings:

1. Touch 
2. Touch Set Menu 
3. Touch Sound Settings 

4. The first time you bring in your own sound, touch the sound setting you wish to alter. Touch User Defined and My Files will open. Find your sound file and touch the OK icon. The name of the loaded sound file is shown next to the icon.



5. To change a User Defined sound, Touch and Hold the arrow on your User-Defined Sound icon and you will enter My Files and be able to choose a different sound.

