


The Holiday files are Husqvarna Viking Designer SE and Designer Diamond stitches. To use them please do the following:


For both the Designer SE and the Designer Diamond:

Save the zip file to your desktop, or location of your choice on your computer. Double Click the file to open it. Select the zip file for your machine, either the Designer SE or Designer Diamond.



Click Extract. A window will open asking you where you want to extract the file to. Select a location on your computer to save a backup copy of the stitches.

Insert your USB Embroidery Stick into the USB port on your Computer. Click Extract again and extract the files to your USB Embroidery Stick.



Designer SE:

1. Place the Designer SE in Sewing Mode.
2. Insert your USB Embroidery Stick
3. Touch the file folder to open the File Manager.
4. Touch the USB Devices icon and select the Embroidery stick.
5. Touch the Load button.
6. Select the stitch you wish to use.
7. Touch the Load button. The new stitch is ready to stitch.

The stitches can be saved in the U Menu if you wish to save them to the Designer SE.

Designer Diamond:

1. Place the Designer Diamond in Sewing Mode.
2. Insert your USB Embroidery Stick.
3. Touch PROG on the lower right corner of the screen.
4. Touch the file folder to open the File Manager.
5. Touch the USB Devices icon and select the Embroidery stick.
6. Touch the Open folder icon on the right.
7. Select the stitch you wish to use.
8. Touch the OK button. The new stitch is ready to stitch.

The stitches can be saved in the U Menu if you wish to save them to the Designer Diamond.