

Saving U Menu Stitches on your Husqvarna Viking USB Embroidery Stick

When you update your Husqvarna Viking Designer SE, it will delete any saved stitches in the U Menu. To save them, create a folder on your USB Embroidery Stick and save them in that folder. One stitch will be saved at a time.

1. Be sure you are in Sewing Mode.
If you are in Embroidery Mode,



2. Touch 

3. Touch  and select the "U" Menu

4. Highlight the first stitch.

5. Touch  Save As.

6. Type in the name of the design.



7. Touch  USB Stick Icon.

8. Touch 

9. Touch 

10. Touch  to create a new folder.


11. Type in the name of the folder, "Stitches".

12. Touch 

13. Click on the folder icon to open the folder.

14. Touch 

15. Before you save the next stitch,



To open the saved stitches:

1. Touch  .

2. Touch  .

3. Select  .

4. Select your stitch.

5. Touch  .