

# Designer SE update version 12124

## Cut jump stitches


The Designer SE Limited Edition features the automatic function Cut jump stitches. This function saves you time trimming after the embroidery is completed. Select Cut jump stitches in the Set Menu. As you embroider, the Designer SE Limited Edition will trim the top jump stitch thread and pull the thread end to the underside of the fabric.



**NOTE:** Only designs marked “Cut jump stitch trim command for Designer SE” are programmed for Cut jump stitches.

Jump stitch trim commands can be added to any design using the Husqvarna Viking 4D Software. Instructions can be found in the 4D Design Enhancer within the 4D Stitch Editor Module.



Some embroidery designs you purchase may have trim commands in them. To check this, look at the design in Stitch Editor to see the trim command symbol in the design or you can stitch them out.



*Go to Embroidery Stitch Number*



## Go to Embroidery Stitch Number

Select a color and touch the Go to stitch icon , a keypad pop-up opens. Enter the number of the stitch in that color you want to go to. Close the pop-up by touching . The Designer SE Limited Edition will go directly to that stitch.



*Time left*



## Time left

The time to sew the selected color is displayed above the Step by Color button, and is recalculated as the stitches in that color are sewn.

## Thread color name

By selecting Quick Help and touching a color, the manufacturer's name of the thread color is displayed on the screen. This makes it easy to select the colors for your embroidery.




*Thread color name*

## New Stitches!

- Stitches G44-45 (Children stitches) Great for embellishing fun projects for adults too!

- Stitches N42-44 (Fashion stitches) 3 new Fashion stitches to add a stylish touch to your projects.

## G:2 – Children Stitches, 44-45



## N:2 – Fashion Stitches, 42-44

