

Table Cloth

Designed & Created by Lena Mattsson and Karin Larsson

Approx. size: 28" (70 cm) square



Sewing Supplies

- Husqvarna Viking Lena sewing machine
- 1 yard (90 cm) cotton or cotton blend
- Sewing thread to match the fabric, green and red
- Pictogram pen (412 08 38-48)

Cut & Sew

Cut the fabric 32" (80 cm) square. Mark with pictogram pen a line 4" (10 cm) from the outer edge on all sides. Turn the fabric under along the marked line and press.

Thread your sewing machine with sewing thread to match the fabric on top and in the bobbin. Snap on presser foot A and select a straight stitch, stitch length 2.5. Sew a mitered corner by folding the edges to the right side along the fold marks. Pin and mark a 45 degree angle.




Illustration A

Illustration A.

Sew the corner diagonally on the marked line.

Illustration B

Repeat for all four corners. Trim excess fabric, press seam open and turn right side out. Press.

Mark with pictogram pen a line 2 ¾" (7 cm), 3 ¼" (8 cm) and 3 ½" (9 cm) from the folded edge on all sides.







Illustration B.

Thread your sewing machine with red sewing thread on top and in the bobbin. Select reinforced straight stitch  and sew along the marking 2 ¾" (7 cm) from the edge.

Rethread with green sewing thread on top and in the bobbin. Snap on presser foot B and select a reinforced zigzag stitch . Sew along the marking 3 ¼" (8 cm) from the edge. Trim excess fabric on the back as close to the zigzag seam as possible.

Rethread with red sewing thread again. Snap on presser foot A and select a reinforced straight stitch . Sew along the marking 3 ½" (9 cm) from the edge.



 **Husqvarna**

VIKING