


No Hammer Candlewicking Stitch

By Peggy Dilbone, Husqvarna Viking Educator and Martha Pullen Licensed Educator

Here is an alternative way to program Candlewicking stitches. Peggy is the Martha Pullen coordinator for Husqvarna Viking and teaches all the classes at the Martha Pullen Sew Beautiful Schools. This is her “recipe” for perfect Candlewicking! These instructions are adapted from instructions written by Lynn Downing.

No Hammer Candlewicking Stitch Designer Se

1. Snap on your Candlewicking Foot #412 51 08-45. Thread with 60 wt. cotton thread or 40 wt. embroidery thread on top and 60 wt. cotton thread in the bobbin. Reduce the tension slightly, if necessary until you don't see any bobbin thread on top.
2. Touch PROG.
3. Select the T MENU
4. From the right hand screen select
5. ▼, ▲, ▼, ▲, ▼, ▲, ▼, ▲, ▼
6. From the Stitch menu select A1:2 Stitch Length 0.0
7. A1:2 Stitch Length 4.0
8. To save in your U Menu (Favorite Stitches) just touch . Select the spot you would like it to be saved to. It will now be saved for you to use in the future. To bring it up later, just select U Menu, then the stitch.

No Hammer Candlewicking Designer I:

1. Snap on your Candlewicking Foot #412 51 08-45. Thread with 60 wt. cotton thread or 40 wt. embroidery thread on top and 60 wt. cotton thread in the bobbin. Reduce the tension slightly, if necessary until you don't see any bobbin thread on top.
2. Touch Program
3. Designer I: MENU T: On Screen select 9 –16 (box in lower left corner) touch arrows as shown.
T15 → T10 ← four times
4. Touch → T15
5. Touch FIX
6. Touch MENU
7. MENU A: A2 Touch ADJUST, SL 3.5 Touch OK.
8. Touch REP

Another great candlewick stitch was created by Diana Cedolia:

Program: D43 Stitch Length 0, Stitch Width 2.0
D28 Stitch Length 1.5
D25
D25
Touch REP, Sew.